5033

## SAFETY INSTRUCTION

IMPORTANT: NEVER attempt any work without shutting off the electricity.

- Read all instructions before installing.
- System is intended for installation by a qualified electrician in accordance with the National Electrical Code and local regulations.
- Place the wall switch in the "OFF" position.
- Go to the main fuse box, or circuit breaker. Unscrew the fuse(s) or switch "OFF" the circuit breaker switch(es) that control the power to the space that you are working on.

#### CAUTION:

All parts must be used as indicated in these instructions. Do not substitute any parts, leave parts out, or use any parts that are worn out or broken. Failure to follow this instruction could invalidate the UL listing of this fixture.


# AVERTISSEMENT

#### IMPORTANT : COUPEZ L'ÉLECTRICITÉ AVANT TOUTE MANIPULATION.

- Lisez toutes les instructions avant d'installer.
- Système est destiné à être installé par un électricien qualifié en conformité avec le code national de l'électricité et les règlements locaux.
- Placez l'interrupteur mural en position d'arrêt (« OFF »).
- Accédez au panneau central de disjoncteurs ou de fusibles de votre demeure et placez l'interrupteur principal en position d'arrêt (« OFF »). MISE EN GARDE

Toutes les pièces doivent être utilisées tel qu'il est indiqué dans ces instructions. Ne remplacez pas les pièces, n'en laissez pas de côté et ne les utilisez pas si elles sont usées ou brisées. Le non-respect de ces instructions peut annuler l'homologation UL du luminaire.

## THIS INSTRUCTIONS APPLY TO THE MODELS BELOW:



5033

Fixture Accessory (included in box)



Outdoor Rated Wire Nut For Model: 5033 Qty: 2pcs 7EAC352401


waclighting.com Phone (800) 526.2588 Fax (800) 526.2585 Headquarters/Eastern Distribution Center 44 Harbor Park Drive Port Washington, NY 11050 **Central Distribution Center** 1600 Distribution Ct Lithia Springs, GA 30122 Western Distribution Center 1750 Archibald Avenue Ontario, CA 91761

LANDSCAPE LIGHTING

## 5033

# CONCRETE POUR INSTALLATION

- 1. Turn the main power off.
- Install wiring and conduit (use 1/2" NPT) with Concrete Pour Canister at desired position, plug all un-used holes (Fig. 1) Secure the canister to the bottom of the application ground by using screws.
  Note: For proper alignment, make sure the flat edge of the canister is parallel to the wall. (Fig. 2)
- 3. Insert Plastic Cap into Concrete Pour Canister (Fig. 1)
- 4. Pour concrete until it's flushed with the Plastic Cap. (Fig. 3) Note: NO CONCRETE ENTERS THE BOX. USE SAND OR GRAVEL FOR PROPER DRAINAGE.
- 5. After concrete has cured, crack concrete and remove Plastic Cap using a corkscrew or similar tool. (Fig. 4)
- 6. Connect fixture leads to box wiring using supplied outdoor rated wire nuts. Make sure all power is off while wiring LED fixture.
- 7. Apply a smear of plumber's silicone to O-rings. Insert LED fixture into flange with a twisting motion. Make sure the trim is flushed with the top of the poured concrete.
- 8. To match different height requirements, use extenders and cover plates. (Fig. 5)



λΑ

LANDSCAPE LIGHTING

Fig.5

1/2" NPT pipe extender

4" Junction box cover

(Not Provided)

(Not Provided)

waclighting.com Phone (800) 526.2588 Fax (800) 526.2585 Headquarters/Eastern Distribution Center 44 Harbor Park Drive Port Washington, NY 11050

2

**Central Distribution Center** 1600 Distribution Ct Lithia Springs, GA 30122 Western Distribution Center 1750 Archibald Avenue Ontario, CA 91761

# 5033

#### SOFTSCAPE INSTALLATION

- 1. Turn the main power off.
- 2. Dig a hole at the point of application. Make sure the hole measures at least 4-5/8 inches in diameter and 10 inches in depth. (**Fig.6**)
- 3. Place a layer of pea gravel (3 inches) at the base of the hole to help with drainage.
- 4. Connect the fixture wires to landscape wires coming from the transformer using the outdoor rated direct burial wire nuts provided.
- 5. Place the fixture in the hole and repack the soil to hold it in place. Make sure the trim is flush with the ground.


#### CUSTOMIZE SETTING

This fixture is equipped with three customizable settings: Dimming Adjustment, Beam Angle Adjustment, and Beam Aiming Adjustment. It can be pre-set into desired settings by taking the light engine assembly out from the fixture housing. (**Fig. 7**)

- 1. Unscrew Face Plate Screws with hex L-key.
- 2. Take out the Face Plate, Gasket, Front Glass.
- 3. Pull the Light Engine out of the Fixture housing.

**Note:** Light Engine can be taken out remotely by disconnecting the Quick Connector. Users can later reconnect it back into the housing after all desired settings are been made.

To ensure IP67 rating of the fixture, use a minimum force of 2.5 N\*M/22 lbsf.in to tighten the screws of the face plate.




waclighting.com Phone (800) 526.2588 Fax (800) 526.2585 Headquarters/Eastern Distribution Center 44 Harbor Park Drive Port Washington, NY 11050 **Central Distribution Center** 1600 Distribution Ct Lithia Springs, GA 30122 Western Distribution Center 1750 Archibald Avenue Ontario, CA 91761

# WAC LANDSCAPE LIGHTING

## 5033

#### **DIMMING ADJUSTMENT:**

- 1. Use a Philips head screw driver to adjust the dimming dial. (Fig. 8)
- Rotate until the arrow on the dial is pointed at the desired 2. wattage. The wattage may be adjusted to the pre-existing tabs or any value in between.
- The lower the wattage, the dimmer the fixture will be 3.



LANDSCAPE LIGHTING

Headquarters/Eastern Distribution Center 44 Harbor Park Drive Port Washington, NY 11050

**Central Distribution Center** 1600 Distribution Ct Lithia Springs, GA 30122

Western Distribution Center 1750 Archibald Avenue Ontario, CA 91761

# **BEAM ANGLE ADJUSTMENT:**

- Rotate the Beam Changing Bracket by hand to adjust 1. the beam angle
- 2. Use the Beam Angle Indicator to mark your beam angle
- Beam angle can be set in between 20° to 60° 3.

AIMING ADJUSTMENT(MODEL 5033):

Note: Aiming adjustment applies for Model 5033

right as required. (Fig. 10)

desired angle full stop.

1.

2.

Note: Beam angle is pre-set to be 60°, 50°, 40°, 30°, and 20°.

# 5033

•

# ACCESSORIES:

*Rock Guard* – Protects fixture front glass from large falling objects.

To Install (Fig. 11):

- 1. Unscrew the Face Plate Mounting Screws.
- 2. Put the Rock Guard on top of the fixture face plate, make sure to match up the mounting index arrow on the fixture and rock guard.
- 3. Use the same Face Plate Mounting Screws to mount the Rock Guard onto the fixture.

Concrete Pour Canister & Cap – used to install fixture in

Please visit the previous Concrete Pour Installation instructions.



Fig.11




Fig.12


Plastic Cap

To take out the light engine (**Fig. 13**):

concrete pour applications.

To install (Fig. 12):

- 1. Use the light engine lifting handle to rotate the light engine and align it with the arrow marking insided the fixture housing.
- 2. Pull the light engine upward to take it out from the housing



waclighting.com Phone (800) 526.2588 Fax (800) 526.2585 Headquarters/Eastern Distribution Center 44 Harbor Park Drive Port Washington, NY 11050 **Central Distribution Center** 1600 Distribution Ct Lithia Springs, GA 30122 Western Distribution Center 1750 Archibald Avenue Ontario, CA 91761