

PALECEK®

601 PARR BOULEVARD | RICHMOND | CA 94801

Carolina Floor Lamp

297279

IMPORTANT SAFETY INSTRUCTIONS:

- These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning the assembly and installation of this lighting fixture.
- Never use with an extension cord. Do not alter the plug. Do not attempt to defeat this safety feature.
- This fixture has been rated for up to one (1) **100-watt maximum E26 medium-base bulb** or one (1) **9-Watt LED bulb**. To avoid the risk of fire, do not exceed the recommended lamp wattage.
- This lamp is meant for outdoor use, **SUITABLE FOR WET LOCATIONS**.
- **Save these instructions.**

WARNING:

- **To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the light fixture and allow it to cool prior to replacing the light bulb.**
- **Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.**
- **Keep flammable materials away from lit bulb.**

ASSEMBLY:

- Remove all parts and hardware from box along with any plastic protective packaging.
- Use the guiding nut (A) to align the lamp pole with the base.
- Insert the lamp pole screw (B) through the base (C) and the metal gasket (D). Tighten the Butterfly Nut (E).
- Pull the electrical cord through the exit hole gently.
- Insert one **bulb** (not included) into the socket. **DO NOT EXCEED THE RECOMMENDED WATTAGE.**
- Fix the Glass Shade (F) onto the Glass Shade Holder (G) and twist to tighten.
- Slide Rattan Shade Spider (H) between Washer (I) and Glass Shade Holder (G).
- Insert Shade Screws through the washer into holes of Shade Spider (H) and Shade Screws (J) gently to fix the Shade.

Parts List:

- A) Guiding Nut
- B) Lamp Pole Screw
- C) Base
- D) Gasket
- E) Butterfly Nut
- F) Glass Shade
- G) Glass Shade Holder
- H) Shade Spider
- I) Washer
- J) Shade Screws (2x)

