

# SONNEMAN

A WAY OF LIGHT

Assembly Instructions for item 6019  
Puri Series - Large Pendant

**Important:** Always disconnect the power before installing or replacing bulbs and before cleaning or other maintenance.

This light should be installed by a licensed electrician

### LAMP INSTALLATION AND ASSEMBLY

1. Shut off power to the outlet box. (fig. A)
2. Install A19 bulbs. (not included)
3. Attach shade to fixture by placing shade spider washer over upper threaded stem and securing with small washer and upper stem.
4. Determine the height at which the fixture is to be hung.  
Screw together stem sections to achieve desired length.
5. Attach the universal mounting plate to the outlet box, secure with outlet box screws.
6. Make appropriate electrical connections using wire nuts:
  - a. Connect the fixture's live wire (black) to the live outlet box wire.
  - b. Connect the fixture's neutral wire (white) to the neutral outlet box wire.
  - c. Connect fixture's ground wire (green or uncoated) to the ground outlet box wire. If no ground is present in outlet box, connect fixture's ground wire to the mounting plate using the green screw (included).
  - d. Carefully place connections in outlet box.
7. Attach canopy to universal mounting plate, secure with canopy nuts.
8. Line up the holes of glass and big washer, and attach them to lower threaded stem, secure with finial.
9. Restore power to the fixture.

### CARE INSTRUCTIONS

Dusting — Use a clean, dry cloth.  
Cleaning — To protect the finish, avoid any harsh abrasives or chemicals.

