

Simple Banded Hanging Shade Pandent Item # BBL 5110

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING *** SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

- 1. Carefully remove all parts from the carton.
- 2. Remove canopy ring (E) from mounting loop (C) by turning in a clockwise direction.
- З. Attach mounting strap (A) to ceiling outlet box and secure with mounting screws (B).
- 4. Slide canopy ring (E) and canopy (D) on chain (F).
- 5. Attach chain (F) to hanging loop (G) and mounting loop (C) by opening/closing end link of chain.
- Feed wire through the chain (F), canopy ring (E), canopy (D) and mounting loop (C). 6
- 7. Attach the bare copper ground wire from the fixture to the ground junction box wire (usually green or copper), fasten together with a plastic wire connector. Tightly wrap the wire connector with electrical tape. Be sure no wire strands are exposed. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
- 8. Connect neutral wire from fixture (ridges molded wire) to the neutral wire from the junction box (usually white). Fasten both wires together with a plastic wire connector and tightly wrap the wire connector with electrical tape. Be sure no wire strands are exposed.
- Connect the hot wire from the fixture (smooth wire) to the hot wire (usually black) from the 9. junction box. Fasten both together with a plastic wire connector and wrap the connection with electrical tape. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.
- Tuck the wire connections neatly into the ceiling outlet box. 10.
- Slip canopy (D) to mounting strap (A) and secure with canopy ring (E). 11.
- Insert light bulbs (not included) into sockets. 12.
- 13.
- Attach shade (L) to the stem on bottom of hanging loop (G) and secure by tigten ring (H). Remove finial (K) from rod (I), attach diffuser (J) to the bottom of shade (L), let the bottom nipple of 14.
- rod (I) pass through the hole of diffuser (J) and secure with finial (K).
- Restore power and test fixture. Installation is complete. 15.

*** Clean with a dry, soft cloth only. Use no harsh abrasives or chemical agents.

VISUAL COMFORT & CO. Fre 1987

