

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: DSI06 NAME: Bingham Pendant
MATERIAL TYPE: BRASS FINISH: ANTIQUE BRASS
SOCKET TYPE: TYPE A (E26) SOCKET QTY: 1
BULB WATTAGE: 60W VOLATGE: _____
ITEM NET WEIGHT: _4.800 KGS. ____

PARTS INCLUDED:

MOUNTING PLATE	QTY:1	_____	QTY:	_____
CANOPY	QTY:1	_____	QTY:	_____
LOOP	QTY:1	_____	QTY:	_____
SOCKET ASSEMBLY	QTY:1	_____	QTY:	_____
HANGING PIPE	QTY:1	_____	QTY:	_____
3"				
HANGING PIPE 6"	QTY:1	_____	QTY:	_____
HANGING PIPE	QTY:2	_____	QTY:	_____
12"				
	QTY:	_____	QTY:	_____

HARDWARE INCLUDED:

Mounting Screws	2	Canopy Screws	2
Plastic Wire Connectors	2	Hexangular Screw	3
Green Ground Screw	1	Allen Wrench	1

TO INSTALL YOU WILL NEED:

- 2 people recommended.
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



TO ASSEMBLE:

1. Shut off the main electrical supply from the main fuse box/ circuit breaker.

Carefully unpack all fixture parts and hardware and lay them on a soft surface for assembly.

2. Gently pull wiring down from ceiling junction box and allow to hang.
3. Remove the mounting plate from the canopy by unscrewing the collar.
4. Carefully inspect the pendant's fixture wires.
Neutral fixture wire: White
Hot fixture wire: Black
Ground wire: Green
5. Wrap the ground wire of lamp assembly and ground wire of junction box together and fasten together with a wire nut and wrap the connection with electrical tape.
6. Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
7. Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape.

DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.

8. Gently tuck the wire connections neatly into the ceiling junction box.
9. Place the mounting plate over the center of the ceiling junction box.
10. Align holes in mounting plate with holes in junction box and attach with two mounting bolts. Secure bolts with a Phillips head screwdriver.
11. Push canopy up over the mounting plate until it is flush with the ceiling.
12. Push collar through hole in canopy and thread onto nipple on the mounting plate. Secure by turning collar clockwise until canopy is flush with the ceiling.

Restore power to junction box and test fixture. Insert Type (A) bulb into fixture, **DO NOT EXCEED THE SPECIFIED WATTAGE OF PENDANT.**

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call **1-800-338-2150**
Arteriors Home: **972.488.9800** Arteriors Contract: **972.488.9800 Ext.321**

ARTERIOS