# **ASSEMBLY INSTRUCTIONS**

## ITEM DESCRIPTION:

ITEM NO.: 42514 NAME: Arianna Large Pendan

MATERIAL TYPE: Glass FINISH: Antique Mercury

SOCKET TYPE: E12 SOCKET QTY: 1

BULB WATTAGE: 25 W

VOLTAGE: 110-120 V ITEM NET WEIGHT: 3LBS

#### PARTS INCLUDED:

Mounting Plate	Qty: 1 Pc
Canopy	Qty: 1 Pc
Loop	Qty: 1 Pc
Socket Assembly	Qty: 1 Pc

#### HARDWARE INCLUDED:

	Mounting Screws	2 Pcs	Canopy Screws	4 Pcs
	Plastic Wire Connector	2 Pcs	Hexangular Screws	1 Pc
	Green Ground Screw	1 Pc	Allen Wrench	1 Pc

#### TO INSTALL YOU WILL NEED:

• 2 people recommended • Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



#### TO ASSEMBLE:

- 1. Shut off the main electrical supply from the main fuse box/circuit breaker.
- 2. Carefully unpack all fixture parts and hardware and lay them on a soft surface for assembly.
- 3. Gently pull wiring down from the ceiling junction box and allow it to hang.
- 4. Remove mounting plate from the canopy by loosening the canopy screws with a screwdriver.
- 5. Determine the chain length desired and, if necessary, remove the extra links from the chain and reconnect the chain to the nipple (hook) assembly. The electric supply wire that is woven through the chain should be cut off 12 inches longer than the chain. Cut the braided copper ground wire the same length. Split the supply wire down the center by a length of 3 inches and strip 3/4 inch of insulation off of the end of each wire. If you look very closely, you will notice that the plastic insulation of one of the two split wires has a rib on the outside edge. This ribbed wire is the "neutral" wire and the other is the "hot" wire; you will need to remember the difference when connecting these to the house wires in the electrical outlet box.
- 6. Insert the two stripped wires and the braided copper ground wire through the nipple assembly, locknut, mounting plate, and mounting strip. Using the wire nuts, attach the ribbed wire to the white "neutral" house wire and the un-ribbed wire to the black "hot" house wire. Secure the wire nuts with black electrical tape. Connect the braided copper ground wire to the green ground screw marked "GRD" on the mounting strip. It is imperative that the outlet box in your home is properly grounded.
- 7. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED. Always make sure that no wire strands are outside of the wire nut connectors
- 8. Gently push the wiring back into the outlet box. Screw the nipple assembly, locknut, and canopy plate into the mounting strip and turn until the canopy is snug against the ceiling. Do not support the fixture from the electrical cord.

  9. Insert bulbs (not included) into the sockets. DO NOT EXCEED SPECIFIED WATTAGF
- 10. Restore power to the junction box and test the fixture.

### **CARE INSTRUCTIONS:**

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

ARTERIORS

For customer service questions call 1-800-338-2150