ASSEMBLY INSTRUCTIONS **ITEM DESCRIPTION:** ITEM NO.: 45082 NAME: Arya Chandelier FINISH: Black Stained MATERIAL TYPE: Wood SOCKET TYPE: E26 Keyless SOCKET QTY: 3 BULB WATTAGE: 60W/16W CFL/13W LED VOLTAGE: 110-120 V ITEM NET WEIGHT: 28LBS Figure 1 Figure 3 TO ASSEMBLE: Junction Roy SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE 1. (D) **BOX/CIRCUIT BREAKER.** \$(B) 2 Please check you have all parts before beginning assembly. (D) Secure the cross-bar (D) to the Junction Box with the Mounting 3. Screws (A). Tighten until snug. (Figure 1) 4. Establish electrical connections: a) Connect the NEUTRAL FIXTURE WIRE (has ridges molded on the outside insulation) to the NEUTRAL Figure 2 JUNCTION BOX WIRE (usually white insulation). Fasten each together with a wire connector (C) and wrap the connection with electrical tape. Be sure that no wire strands are exposed. b) Junction Box Connect the HOT FIXTURE WIRE (has insulation that is smooth) to the HOT JUNCTION BOX WIRE (usually black insulation). Fasten each Junction Box Wires together with a wire connector (C) and wrap the connection with Fixture Wires electrical tape. Be sure that no wire strands are exposed. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED. c) If the J-Box includes a ground wire, attach the GROUND WIRE of the fixture to the GROUND J-BOX WIRE. Fasten the PARTS INCLUDED: wires together with a plastic wire connector (C) and wrap the connection with electrical tape. Be sure that no wire strands are Main Body Qty: 1 exposed. If there is no ground wire in the J-Box, use a screwdriver to Mounting Plate Qty: 1 secure the end of the chandelier ground wire to the GREEN screw Qty: 1 located on the cross-bar (D). Wrap the wire around the screw Canopy once clockwise and then tighten the screw. Make sure that the wire is held firmly by the screw and did not slip out during tightening. (Figure 2) 5. After all connections are made attach the canopy (E) to the crossbar (D). Align the holes of the side portions of the crossbar with the holes located in the side of the canopy. Using a screwdriver Insert the canopy screws (B) through each hole of the canopy and into threaded engagement with the cross bar. Do not over-tighten the screws. (Figure 3) Insert (3) 60-watt maximum TYPE A standard incandescent light 6. HARDWARE INCLUDED: bulbs (not included) into the sockets. DO NOT EXCEED THE RECOMMENDED WATTAGE. Mounting Screws 2 Pcs 7. Restore power to ceiling outlet junction box and test fixture. Plastic Wire Connector 3 Pc Canopy Screw 2 Pcs TO INSTALL YOU WILL NEED: • 2 people recommended • Phillips Screwdriver Electrical Tape These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation of this chandelier. CARE INSTRUCTIONS: Wipe with a soft, dry cloth. To protect finish, avoid the use of We strongly suggest that all hard-wired fixtures must be installed by a chemicals and household cleaners. professional electrician. ARTERIORS For customer service questions call 1-800-338-2150