

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: 42081	NAME: Edith Pendant
MATERIAL TYPE: Brass	FINISH: Vintage Brass
SOCKET TYPE: E26 Keyless	SOCKET QTY: 1
BULB WATTAGE: 60W/16W CFL/13W LED	
VOLTAGE: 110-120 V	ITEM NET WEIGHT: 7LBS



TO ASSEMBLE:

- SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.**
- Gently pull wiring down from ceiling junction box and allow to hang.
- Remove mounting plate from the canopy by unscrewing the collar.
- Carefully inspect the chandelier's fixture wires. The neutral fixture wire has very fine ridges molded into its plastic covering. The hot fixture wire has a smooth covering. The bare copper wire is the ground wire.
- Wrap ground wire of socket assembly and ground wire of junction box together and fasten together with a wire nut and wrap the connection with electrical tape.
- Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
- Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
- Gently tuck the wire connections neatly into the ceiling junction box.
- Pass electric cable through canopy and tighten the last pipe to the collar fixed on the canopy.
- Included are (1) 6" pipe and (2) 12" pipes. Determine which of these you will need to reach your desired length. At least (1) 6" pipe must be used. Pass the attached electric cable through the desired amount of pipes, keeping the threaded part of the pipes toward the ceiling.
- Screw each pipe to each other starting with the one closest to the Main Body and moving upwards to the canopy.
- There is an Allen screw with each pipe and which should be tightened with the help of Allen wrench included with the hardware once pipes are assembly with each other as per desired height.
- Align holes in mounting plate with holes in junction box and attach with two mounting bolts. Secure bolts with a Phillips head screwdriver.
- Push canopy up over the mounting plate until it is flush with the ceiling.
- Push collar through hole in canopy and thread onto nipple on the mounting plate. Secure by turning collar clockwise until canopy is flush with the ceiling.
- Insert (1) TYPE A 60W bulb (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
- Restore power to junction box and test fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

PARTS INCLUDED:

Main Body	Qty: 1
Mounting Plate	Qty: 1
Canopy	Qty: 1
Pipes	Qty: 3 (1) 6" & (2) 12"
Socket Assembly	Qty: 1

HARDWARE INCLUDED:

Mounting Screws	2 Pcs	Canopy Screws	4 Pcs
Plastic Wire Connector	2 Pcs	Allen Screws	2 Pcs
Green Ground Screw	1 Pc	Allen Wrench	1 Pc

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.

For customer service questions call 1-800-338-2150

ARTERIOS