ASSEMBLY INSTRUCTIONS ITEM DESCRIPTION: ITEM NO.: DS49002 NAME: Mercury Sconce MATERIAL TYPE: Steel FINISH: Antique Brass SOCKET TYPE: E26 SOCKET QTY: 1 BULB WATTAGE: 40W/10W CFL/9W LED VOLTAGE: 110-120 V ITEM NET WEIGHT: 4LBS TO ASSEMBLE: Н А (; Remove all packing contents and parts from the 1. carton(s) carefully. 2. Please be sure you have all parts indicated before you begin assembly. 3. Turn off power to the junction box where the lamp will be installed. 4. Pull the electrical cord of "j box"through the exit hole of the mounting plate (A). 5. Attach the ground wire from the fixture to the ground junction box wire from the outlet (usually green or bare wire). Fasten each together with a plastic wire C connector (E) and wrap the connection with electrical tape. if your outlet box does not have a ground wire, insert the green ground screw (D) into the mounting plate (A) facing down, and wrap the fixture's bare ground wire around the ground screw. It is imperative С that the outlet box in your home be properly grounded. 6. Connect the neutral fixture wire to the neutral junction box wire (usually white). Fasten each together with a PARTS INCLUDED: wire connector (E) and wrap the connection with (A) Mounting Plate Qty: 1 electrical tape. Be sure no strands are exposed. (B) Back Plate 7. Connect the hot fixture wire to the hot junction box Qty: 1 wire (usually black). Fasten each together with a (C) Set Screws Qty: 3 plastic wire connector (G) and wrap the connection (D) Green Ground Screw Qty: 1 with electrical tape. Be sure no wire strands are exposed. do not reverse the hot and neutral connections or safety will be compromised. 8. Gently tuck the wire connections neatly into the ceiling junction box. HARDWARE INCLUDED: Drill the anchor (K) to the wall first, attach the 9. (E) Plastic Wire Connector 2 Pc (H) Anchors 4 Pc mounting plate (A) to the outlet box using the mounting screws (F). Tighten with a screwdriver (J). (F) Mounting Screws 2 Pc (I) Strengthening Screws 4 Pc Then screw strenghthened screws (I) into the anchors. (G) Allen Wrench 1 Pc Attach the back plate (B) to the mounting plate (A) 10 using the enclosed plate screws (C). Tighten screws with allen wrench (G). Install 1 type 40w bulb (or cfl/10w, or led 9w bulb, not 11 included) into threaded socket. do not exceed TO INSTALL YOU WILL NEED: specified wattage. · 2 people recommended Phillips Screwdriver 12. Restore power to the junction box and test fixture. These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation. CARE INSTRUCTIONS: Wipe with a soft, dry cloth. To protect finish, avoid We strongly suggest that all hard-wired fixtures must the use of chemicals and household cleaners. be installed by a professional electrician. ARTERIORS For customer service questions call 1-800-338-2150