

## Assembly Instruction

3010/3011/85010/85011

1. Put the post cup on the post
2. Place the glass in the cage
3. Fix the cage and the nog with the screw
4. Fix the top cover by the finial

