

Carolina Table Lamp

298979

IMPORTANT SAFETY INSTRUCTIONS:

- These instructions are provided for your safety. It is very important that they are read carefully and completely before beginning
 the assembly and installation of this lighting fixture.
- Never use with an extension cord. Do not alter the plug. Do not attempt to defeat this safety feature.
- This fixture has been rated for up to one (1) **60-watt maximum E26 medium-base bulb**or one (1) **9-Watt LED bulb**. To avoid the risk of fire, do not exceed the recommended lamp wattage.
- This lamp is meant for outdoor use, SUITABLE FOR WET LOCATIONS.
- Save these instructions.

WARNING:

- To reduce the risk of fire, electrical shock or personal injury, always turn off and unplug the light fixture and allow it to cool prior to replacing the light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.

ASSEMBLY:

- Remove all parts and hardware from box along with any plastic protective packaging.
- Use the guiding nut (A) to align the lamp pole with the base.
- Insert the lamp pole screw (B) through the base (C) and the metal gasket (D). Tighten the Butterfly Nut (E) .
- Pull the electrical cord through the exit hole gently.
- Insert one bulb (not included) into the socket. DO NOT EXCEED THE RECOMMENDED WATTAGE.
- Fix the Glass Shade (F) onto the Glass Shade Holder (G) and twist to tighten.
- Slide Rattan Shade Spider (H) between Washer (I) and Glass Shade Holder (G).
- Insert Shade Screws through the washer into holes of Shade Spider (H)and Shade Screws (J) gently to fix the Shade.

Parts List:

- A) Guiding Nut
- B) Lamp Pole Screw
- C) Base
- D) Gasket
- E) Butterfly Nut
- F) Glass Shade
- G) Glass Shade Holder
- H) Shade Spider
- I) Washer
- J) Shade Screws (2x)

