
# **B7601 INSTALLATION INSTRUCTIONS**



# 🛕 WARNING

#### DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE. READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.



with a plaster frame. The box must be securely mounted to the structure of the building. The mounting bar and hardware supplied should be used. Directly mounting the fixture to the outlet box may make it impossible to correctly align the fixture.

NOTE: For your safety be certain that the circuit breakers controlling outdoor lighting and equipment are GFI breakers

## FIXTURE PREPARATION


1. Remove the fixture, parts and parts bag(s) from the carton.

#### NOTICE:

Before discarding the carton, double check to make certain that all parts are found.

## FIXTURE INSTALLATION

- (Starting at the back), thread the 2 longest screws into the mounting plate. (The green ground screw is the front). Attach the mounting plate to the outlet box. (The green screw should face out).
- 2. Fasten the ground wire to the green or bare copper wire in the outlet box or to the green screw on the crossbar.



 Fasten the white fixture lead wire to the white wire in the outlet box. Fasten the wires together with an approved fastener (wire nut). Starting about 1" below the fastener, tightly wrap the connection With electrical tape so that the connection seals the end of the fastener.

WARNING Make sure that there is no exposed wire or strands that could cause a dangerous short circuit!	
electrical tape	ner
(wire nut)	

- 4. Connect the black fixture lead wire to the black wire in the outlet box. Fasten the joined wires as in step 3.
- To prevent water from flowing into the outlet box ,put a bead of weatherproof caulking or silicone sealant around the inside edge of the back. DO NOT PLUG THE DRAIN HOLE!
- 6. Using the four allen screws, fasten the back plate to the outlet box. (Take away the styrofoam from the glass before installing)
- 7. Install the lamp (light bulbs).(not included) NOTE: This fixture is rated for Max 60 watt type A lamps



8. Restore power to circuit at breaker or fuse box.

