


OTTO F8421 INSTALLATION INSTRUCTIONS



ITEM	DESCRIPTION	PART NUMBER
1	MOUNTING PLATE	HDW-F8421
2	MOUNTING SCREW	HDW-F8421
3	GROUND SCREW	HDW-F8421
4	WIRE NUT	HDW-F8421
5	CANOPY	CAS-F8421
6	SWIVEL	CAS-F8421
7	BALL NUT	HDW-F8421
8	STEM	STM-JH1300-SET
9	FIXTURE ASSEMBLY	FAS-F8421
10	SHADE	SHD-F8421
11	BULB	NOT INCLUDED
12	GLASS	GLS-F8421



- DISCONNECT POWER BEFORE RE-LAMPING OR WIRING THE FIXTURE. READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.
- TO AVOID THE RISK OF FIRE OR SHOCK, FIXTURE MUST BE INSTALLED IN COMPLIANCE WITH ALL
  APPLICABLE NATIONAL AND LOCAL ELECTRICAL/BUILDING CODES. THE INSTALLATION AND
  MAINTENANCE OF THIS UNIT SHOULD BE COMPLETED BY A LICENSED ELECTRICIAN OR CERTIFIED
  FACTORY TRAINED TECHNICIAN.
- CALIFORNIA PROP 65: THIS LIGHTING FIXTURE CONTAINS CHEMICALS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, BIRTH DEFECTS, AND/OR OTHER REPRODUCTIVE HARM. WASH HANDS AFTER USE.
- REMOVE THE FIXTURE, PARTS AND PARTS BAG(S) FROM THE CARTON. BEFORE DISCARDING THE
  CARTON, DOUBLE CHECK TO MAKE CERTAIN THAT ALL PARTS ARE FOUND. INSPECT THE FIXTURE PRIOR
  TO INSTALLATION FOR ANY DAMAGE TO THE FIXTURE.
- DIMMING: THE FIXTURE CAN BE CONTROLLED BY A WALL DIMMING DEVICE. ONLY USE
  TRIAC/ELECTRONIC DIMMER. MAKE SURE THE CARTON IS MARKED FOR USE WITH LED COMPACT
  FLUORESCENT-INCANDESCENT LIGHT SOURCE ONLY. THESE CAN BE PROVIDED BY YOUR LOCAL
  ELECTRICAL DISTRIBUTOR, HOME CENTER, OR HARDWARE STORE.
- PLEASE CLEAN WITH A SOFT, DRY CLOTH ONLY! DO NOT USE CLEANSERS


## **FIXTURE INSTALLATION**

- 1. Feed the wire through the STEM (8) and twist tightly onto the FIXTURE ASSEMBLY (9). Keep adding additional stems until you desired hanging height is met.
- 2. Slide in CANOPY(5) onto the STEM (8), and thread the SWIVEL (6) onto the top end of the STEM (8).
- Pull the wire out from the junction box, and install the MOUNTING PLATE (1) onto the junction box using the MOUNTING SCREWS (2). This fixture is designed to be mounted on standard round or octagon junction box. The junction box must be securely mounted to the structure of the building.
- 4. Trim off the excess wire to a minimum 6" beyond the STEM and strip each wire  $\frac{5}{8}$ ".
- 5. Attach the MOUNTING PLATE (1) onto the junction box using the MOUNTING SCREWS (2). This fixture is designed to be mounted on standard round or octagon junction box. The junction box must be securely mounted to the structure of the building.
- Attach the Ground wire (Green) to the ground inside the junction box (Generally green or bar copper wire) or the GROUND SCREW (3) on the MOUNTING PLATE (1). NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- 7. Connect the fixture lead the ridge(s) to the neutral (Generally white) wire in the outlet box. Fasten the wires together with an approved fastener (WIRE NUT) (4). Starting 1" below the fastener, tightly wrap the connection with electrical tape so that the connections seals the end of the fastener. MAKE SURE THERE ARE NO EXPOSED WIRE OF STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!
- 8. Connect the smooth fixture leads with to the hot (Generally black) wire in the junction box. Fasten the joined wires same as previous step. NEVER REVERSE HOT AND NEUTRAL WIRES. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- 9. Push the wires back into the junction box. Lift up the CANOPY (5) up to the ceiling, and secure with the BALL NUT (7).
- 10. Lift the SHADE (10) up onto FIXTURE ASSEMBLY (9) to fixture and secure using the BALL NUT (7).
- 11. Screw the BULB (11) up into the SOCKET of the fixture. THIS FIXTURE IS RATED FOR 75 WATT LAMP. DO NOT EXCEED THE RECOMMENDED WATTAGE!
- 12. Lift the GLASS (12) up onto FIXTURE ASSEMBLY (9) the fixture and secure using the BALL NUT (7).
- 13. Restore power to the outlet at the breaker or fuse box.

Questions? We're here to help!
Contact us at CustomerService@hvlgroup.com



OTTO F8421 INSTALLATION INSTRUCTIONS



ITEM         DESCRIPTION         PART NUMBER           1         MOUNTING PLATE         HDW-F8421           2         MOUNTING SCREW         HDW-F8421           3         GROUND SCREW         HDW-F8421           4         WIRE NUT         HDW-F8421           5         CANOPY         CAS-F8421           6         SWIVEL         CAS-F8421           7         BALL NUT         HDW-F8421           8         STEM         STM-JH1300-SET           9         FIXTURE ASSEMBLY         FAS-F8421           10         SHADE         SHD-F8421           11         BULB         NOT INCLUDED           12         GLS-F8421			
2 MOUNTING SCREW HDW-F8421 3 GROUND SCREW HDW-F8421 4 WIRE NUT HDW-F8421 5 CANOPY CAS-F8421 6 SWIVEL CAS-F8421 7 BALL NUT HDW-F8421 8 STEM STM-JH1300-SET 9 FIXTURE ASSEMBLY FAS-F8421 10 SHADE SHD-F8421 11 BULB NOT INCLUDED	ITEM	DESCRIPTION	PART NUMBER
3 GROUND SCREW HDW-F8421 4 WIRE NUT HDW-F8421 5 CANOPY CAS-F8421 6 SWIVEL CAS-F8421 7 BALL NUT HDW-F8421 8 STEM STM-JH1300-SET 9 FIXTURE ASSEMBLY FAS-F8421 10 SHADE SHD-F8421 11 BULB NOT INCLUDED	1	MOUNTING PLATE	HDW-F8421
4 WIRE NUT HDW-F8421 5 CANOPY CAS-F8421 6 SWIVEL CAS-F8421 7 BALL NUT HDW-F8421 8 STEM STM-JH1300-SET 9 FIXTURE ASSEMBLY FAS-F8421 10 SHADE SHD-F8421 11 BULB NOT INCLUDED	2	MOUNTING SCREW	HDW-F8421
5 CANOPY CAS-F8421 6 SWIVEL CAS-F8421 7 BALL NUT HDW-F8421 8 STEM STM-JH1300-SET 9 FIXTURE ASSEMBLY FAS-F8421 10 SHADE SHD-F8421 11 BULB NOT INCLUDED	3	GROUND SCREW	HDW-F8421
6 SWIVEL CAS-F8421 7 BALL NUT HDW-F8421 8 STEM STM-JH1300-SET 9 FIXTURE ASSEMBLY FAS-F8421 10 SHADE SHD-F8421 11 BULB NOT INCLUDED	4	WIRE NUT	HDW-F8421
7 BALL NUT HDW-F8421  8 STEM STM-JH1300-SET  9 FIXTURE ASSEMBLY FAS-F8421  10 SHADE SHD-F8421  11 BULB NOT INCLUDED	5	CANOPY	CAS-F8421
8         STEM         STM-JH1300-SET           9         FIXTURE ASSEMBLY         FAS-F8421           10         SHADE         SHD-F8421           11         BULB         NOT INCLUDED	6	SWIVEL	CAS-F8421
9 FIXTURE ASSEMBLY FAS-F8421 10 SHADE SHD-F8421 11 BULB NOT INCLUDED	7	BALL NUT	HDW-F8421
10         SHADE         SHD-F8421           11         BULB         NOT INCLUDED	8	STEM	STM-JH1300-SET
11 BULB NOT INCLUDED	9	FIXTURE ASSEMBLY	FAS-F8421
11	10	SHADE	SHD-F8421
12 GLASS GLS-F8421	11	BULB	NOT INCLUDED
	12	GLASS	GLS-F8421

## **A** ATTENTION PRUDENCE

- DÉBRANCHEZ L'ALIMENTATION AVANT DE REMPLIR OU DE CÂBLER LE LUMINAIRE. LISEZ COMPLÈTEMENT TOUTES LES INSTRUCTIONS AVANT DE COMMENCER L'INSTALLATION
- POUR ÉVITER LE RISQUE D'INCENDIE OU D'ÉLECTROCUTION, LE LUMINAIRE DOIT ÊTRE INSTALLÉ
  CONFORMÉMENT À TOUS LES CODES ÉLECTRIQUES/DE CONSTRUCTION NATIONAUX ET LOCAUX
  APPLICABLES. L'INSTALLATION ET L'ENTRETIEN DE CET APPAREIL DOIVENT ÊTRE EFFECTUÉS PAR UN
  ÉLECTRICIEN AGRÉÉ OU UN TECHNICIEN CERTIFIÉ FORMÉ EN USINE.
- CALIFORNIE PROP 65: CET APPAREIL D'ÉCLAIRAGE CONTIENT DES PRODUITS CHIMIQUES CONNUS PAR L'ÉTAT DE CALIFORNIE POUR PROVOQUER LE CANCER, DES MALADIES CONGÉNITALES ET/OU D'AUTRES DOMMAGES À LA REPRODUCTION. LAVER LES MAINS APRÈS UTILISATION.
- RETIRER LE LUMINAIRE, LES PIÈCES ET LE(S) SAC(S) DE PIÈCES DU CARTON. AVANT DE JETER LE CARTON, VÉRIFIEZ DOUBLE POUR VOUS ASSURER QUE TOUTES LES PIÈCES SONT TROUVÉES. INSPECTER LE LUMINAIRE AVANT L'INSTALLATION POUR TOUT DOMMAGE AU LUMINAIRE.
- GRADATION: LE LUMINAIRE PEUT ÊTRE CONTRLÉ PAR UN DISPOSITIF DE GRADATION MURALE. UTILISER
  UNIQUEMENT UN GRADATEUR TRIAC/ÉLECTRONIQUE. ASSUREZ-VOUS QUE LE CARTON EST MARQUÉ
  POUR UNE UTILISATION AVEC UNE SOURCE DE LUMIÈRE FLUORESCENTE À INCANDESCENTE COMPACTE
  UNIQUEMENT. CEUX-CI PEUVENT ÊTRE FOURNIS PAR VOTRE DISTRIBUTEUR ÉLECTRIQUE LOCAL,
  CENTRE À DOMICILE OU MAGASIN DE QUINCAILLERIE.
- VEUILLEZ NETTOYER UNIQUEMENT AVEC UN CHIFFON DOUX ET SEC! N'UTILISEZ PAS DE NETTOYANTS

## **FIXTURE INSTALLATION**

- 1. Feed the wire through the STEM (8) and twist tightly onto the FIXTURE ASSEMBLY (9). Keep adding additional stems until you desired hanging height is met.
- 2. Slide in CANOPY(5) onto the STEM (8), and thread the SWIVEL (6) onto the top end of the STEM (8).
- Pull the wire out from the junction box, and install the MOUNTING PLATE (1) onto the junction box using the MOUNTING SCREWS (2). This fixture is designed to be mounted on standard round or octagon junction box. The junction box must be securely mounted to the structure of the building.
- 4. Trim off the excess wire to a minimum 6" beyond the STEM and strip each wire  $\frac{5}{8}$ ".
- 5. Attach the MOUNTING PLATE (1) onto the junction box using the MOUNTING SCREWS (2). This fixture is designed to be mounted on standard round or octagon junction box. The junction box must be securely mounted to the structure of the building.
- Attach the Ground wire (Green) to the ground inside the junction box (Generally green or bar copper wire) or the GROUND SCREW (3) on the MOUNTING PLATE (1). NEVER CONNECT GROUND WIRE TO "HOT" WIRE! FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- Connect the fixture lead the ridge(s) to the neutral (Generally white) wire in the outlet box. Fasten the wires
  together with an approved fastener (WIRE NUT) (4). Starting 1" below the fastener, tightly wrap the connection
  with electrical tape so that the connections seals the end of the fastener. MAKE SURE THERE ARE NO
  EXPOSED WIRE OF STRANDS THAT COULD CAUSE A DANGEROUS SHORT CIRCUIT!
- 8. Connect the smooth fixture leads with to the hot (Generally black) wire in the junction box. Fasten the joined wires same as previous step. NEVER REVERSE HOT AND NEUTRAL WIRES. FAILURE TO FOLLOW THIS COULD RESULT IN SERIOUS INJURY OR DEATH!
- 9. Push the wires back into the junction box. Lift up the CANOPY (5) up to the ceiling, and secure with the BALL NUT (7).
- 10. Lift the SHADE (10) up onto FIXTURE ASSEMBLY (9) to fixture and secure using the BALL NUT (7).
- 11. Screw the BULB (11) up into the SOCKET of the fixture. THIS FIXTURE IS RATED FOR 75 WATT LAMP. DO NOT EXCEED THE RECOMMENDED WATTAGE!
- 12. Lift the GLASS (12) up onto FIXTURE ASSEMBLY (9) the fixture and secure using the BALL NUT (7).
- 13. Restore power to the outlet at the breaker or fuse box.

Questions? We're here to help!
Contact us at CustomerService@hvlgroup.com