
### F7353 F7363 INSTALLATION INSTRUCTIONS



# WARNING

DISCONNECT POWER BEFORE RELAMPING OR WIRING THE FIXTURE. READ ALL INSTRUCTIONS COMPLETELY BEFORE STARTING INSTALLATION.



• NOTE: For your safety be certain that the circuit breakers controlling outdoor lighting and equipment are GFI breakers.

#### **FIXTURE PREPARATION**

1. Remove the fixture, parts and parts bag(s) from the carton.

#### NOTICE:


Before discarding the carton, double check to make certain that all parts are found.

#### FIXTURE INSTALLATION

- 1. Determine the overall desired length of the fixture. Assemble the stems one at a time onto the fixture leads. Tape the ends of the leads to a stiff wire (coat hanger) to aid in pulling them through the stems.
- (Starting at the back) thread the 2 mounting screws into the mounting bar. (The green screw is in the front) Attach the mounting bar to the outlet box.
- Thread the small hex nuts onto the long screw. Adjust the screws so that they extend about 3/16" beyond the back plate of the fixture. Lock the hex nuts against the mounting ring.
- Fasten the ground wire to the green or bare copper wire in the outlet box or to the green screw on the crossbar.

## 

Never fasten the ground wire to the black or "hot" wire! Failure to follow this instruction could result in serious injury or death! 5. Fasten the white fixture lead wire to the white wire in the outlet box. Fasten the wires together with an approved fastener (wire nut). Starting about 1' below the fastener, tightly wrap the connection with electrical tape so that the connection seals the end of the fastener.



Glass