

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: PTS15 **NAME:** Como Accent Lamp









MATERIAL TYPE: Rattan, Wicker, Steel

FINISH: Matte Black, Matte Black, Antique Brass

SOCKET TYPE: E26 **SOCKET QTY:** 1

BULB WATTAGE: 60W **VOLATGE:** 110-120V

ITEM NET WEIGHT: 8 Lbs

			
A	B	C	D
			
E	F	G	H

PARTS INCLUDED:

FINIAL (A) QTY 1

COCO MIDRIBS WEAVED DECOR (B) QTY 1

THREADED WASHER (C) QTY 1

SHADE (D) QTY 1

HARP TOP (E) QTY 1


HARP (F) QTY 1

SOCKET (G) QTY 1

SADDLE (H) QTY 1

PRE-ASSEMBLY:

- Remove all parts and hardware from box along with any plastic protecting packaging.
- Do not discard any contents until after assembly is complete to avoid accidentally discarding small parts or hardware.



TO ASSEMBLE:

1. Insert the **harp (F)** into the **saddle (H)** and lower the two harp caps until they cover the two-pronged saddle.
2. Unscrew the **finial (A)** from the **harp top (E)**. Place **shade (D)** over the assembled harp, making sure the top of the harp extends through the hole at the top of the shade. Attach the **finial (A)** and tighten to secure the shade.
3. Insert correct bulb (not included) into the **socket (G)**

CARE INSTRUCTIONS:

- Clean with soft, dry cloth.
- Always avoid the use of harsh chemicals or abrasive cleaners as they may cause damage to the lamp.

IMPORTANT SAFETY INSTRUCTIONS

For safety purposes, this lamp is equipped with a polarized plug (one blade is wider than the other) (For North America Customers Only). If the plug does not fit securely into your outlet, do not force it – contact a professional electrician. Use the plug with an extension cord only if it can be fully inserted into the cord's socket. Never alter the plug in any way. This instruction is provided for your safety. It is important that it is read carefully and completely before assembling the fixture. To avoid risk of fire, do not exceed the recommended wattage.

WARNING:

- To reduce the risk of fire, electrical shock, or personal injury, always turn off and unplug lamp and allow it to cool prior to replacing the light bulb.
- Do not touch bulb when fixture is turned on. Do not look directly at lit bulb.
- Keep flammable materials away from lit bulb.

For customer service questions call 1-800-338-2150

ARTERIOIRS