


ASSEMBLY INSTRUCTION FOR Hollywood Floor Lamp

4174-22

1.0

Model# 4174-22



1. Screw socket holder (D), pole (C), (B) and base (A) together . You may need to pull any excess cord gently through the poles so that these two parts fit.

2. Place the shade (E) onto the socket holder (D) and screw the socket ring (F) onto socket holder (D).

GENERAL PRODUCT INFORMATION:

This product is suitable for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug as a feature to reduce the risk of electric shock (one blade is larger than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless the plug can be fully inserted. **DO NOT ALTER THE PLUG .**

BULB TYPE: Use only with maximum of 1*100 watt incandescent bulbs (bulbs not included).

CAUTION:

DO NOT USE A CFL BULB WITH THIS LAMP.

Use of a CFL bulb with a 3-way touch sensor may result in touch sensor failure/damage to the lamp.

PARTS DIAGRAM

(1) *Shade(E)

(1) * Socket ring(F)