

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: 89453

NAME: Larie Chandelier

MATERIAL TYPE: Steel/Seedy Glass FINISH: Antique Brass/Clear


SOCKET TYPE: E12x2/E26x1

SOCKET QTY: 3

BULB WATTAGE: 60W or/CFL 12W or/LED 10W

VOLTAGE: 110-120 V

ITEM NET WEIGHT: 65LBS



PARTS INCLUDED:

A MOUNTING PLATE	1 PC	G GLASS	63 PCS
B CANOPY	1 PC	H GLASS SCREW	63 PCS
C COLLAR LOOP	1 PC	I E12 SOCKETS	2 PCS
D CHAIN	1 PC	L BULB B(NOT INCL.)	2 PCS
E LOOP	1 PC	M E26 SOCKET	1 PC
F LAMP BODY	1 PC	N BULB T(NOT INCL.)	1 PC

HARDWARE INCLUDED:

K Plastic Wire Connector	2 Pcs	Allen Wrench	1 Pc
J Mounting Screws	2 Pc		
Green Ground Screw	1 Pc		

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



TO ASSEMBLE:

1. Remove all packing contents from the carton(s) carefully. Ensure you have all parts indicated before you begin assembly.
2. Shut off the main electrical supply from the main fuse box/circuit breaker.
3. Remove the mounting plate(a) from the canopy(b) by turning collar loop (c) in a counterclockwise direction.
4. Pull the electrical cord of "j-box" through the exit hole of the mounting plate.
5. Carefully inspect the fixture wires. The neutral fixture wire has very fine ridges molded into its plastic covering. The hot fixture wire has a smooth covering. The bare silver wire is the grounded wire.
6. Attach the ground wire from the fixture to the ground junction box wire from the outlet (usually green or bare wire). Fasten each together with a plastic wire connector (k) and wrap the connection with electrical tape. If your outlet box does not have a ground wire, insert the green ground screw(h) into the mounting plate (a) facing down, and wrap the fixture's bare ground wire around the ground screw. It is imperative that the outlet box in your home be properly grounded.
7. Connect the neutral fixture wire to the neutral junction box wire (usually white). Fasten each together with a wire connector (i) and wrap the connection with electrical tape. Be sure no strands are exposed.
8. Connect the hot fixture wire to the hot junction box wire (usually black). Fasten each together with a plastic wire connector (i) and wrap the connection with electrical tape. Be sure no wire strands are exposed. Do not reverse the hot and neutral connections or safety will be compromised.
9. Gently tuck the wire connections neatly into the ceiling junction box.
10. Attach the mounting plate (a) with nipple to the ceiling outlet box using the enclosed mounting screws (j) and tighten screws with a screwdriver.
11. Push collar loop (c) in canopy (b) and thread onto nipple in mounting plate (a) by turning in a clockwise.
12. Connect the canopy(b) and collar loop(c) with chain(d) through the loop(e)
13. Insert 2 type b 60w bulb (or cfl 12w or led 10w, not included) into the top s sockets(i) and 1 type t 60w bulb (not included) into the bottom socket(m). Do not exceed specified wattage.
14. Attached the glass (g) through the pipe and thread the glass screw(h) to tight to secure the glass shade. Note: starting at the bottom of the glass.
15. Restore power to the junction box and test fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

ARTERIO RS