

ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: 44789 NAME: Ozark Pendant

MATERIAL TYPE: Brass FINISH: Vintage Brass

SOCKET TYPE: E26 SOCKET QTY: 4

BULB WATTAGE: 40W/10W CFL/9W LED

VOLTAGE: 110-120 V ITEM NET WEIGHT: 20LBS

PARTS INCLUDED:

Main Body	Qty: 1
Mounting Plate	Qty: 1
Canopy	Qty: 1
Pipes	Qty: 6 (2) 3", (2) 6" & (4) 12"

HARDWARE INCLUDED:

Mounting Screws	2 Pcs	Allen Screws	2 Pcs
Plastic Wire Connector	2 Pc	Allen Wrench	1 Pc
Green Ground Screw	1 Pc		

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver
- Electrical Tape

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.



TO ASSEMBLE:

- SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER.**
- Carefully unpack all fixture parts and hardware and lay them out on a clear workspace.
- Tighten the main large pipe with main body by rotating it clockwise direction. (Figure 1)
- Tighten the Metal Spoke hook onto the metal disc with dome nut one by one. (Figure 2)
- Included are (2) 3", (2) 6" pipe and (4) 12" pipes. Determine which of these you will need to reach your desired length. At least (1) 3" pipe must be used. Pass the attached electric cable through the desired amount of pipes, keeping the threaded part of the pipes toward the ceiling.
- Screw each pipe to each other starting with the one closest to the Main Body and moving upwards to the canopy.
- There is an Allen screw with each pipe and which should be tightened with the help of Allen wrench included with the hardware once pipes are assembled with each other as per desired height.
- Gently pull wiring down from ceiling junction box and allow it to hang.
- Remove mounting plate from the canopy by unscrewing the collar.
- Carefully inspect the pendant's fixture wires: Neutral fixture wire: White | Hot fixture wire: Black | Ground wire: Green
- Carefully strip the outer insulation cover taking care that the insulation of the inner conductors is not damaged. Strip approximately 3" of the outer insulation cover to expose the three conductor wires. Strip ¼" of the insulation off the three conductor wire.
- Attach the Ground wire from the pendant to the Ground junction box wire (usually Green). Fasten each together with a wire nut and wrap the connection with electrical tape.
- Attach the neutral fixture wire from the pendant to the neutral junction box wire (usually white). Fasten each together with a wire nut and wrap the connection with electrical tape.
- Attach the hot fixture wire from the pendant to the hot junction box wire (usually black). Fasten each together with a wire nut and wrap the connection with electrical tape. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.**
- Gently tuck the wire connections neatly into the ceiling junction box.
- Align holes in mounting plate with holes in junction box and attach with two mounting bolts. Secure bolts with a Phillips head screwdriver.
- Push canopy up over the mounting plate until it is flush with the ceiling.
- Push collar through hole in canopy and thread onto nipple on the mounting plate. Secure by turning collar clockwise until canopy is flush with the ceiling.
- Insert One TYPE A 60W BULB / 16W SBCFL / 13 W SBLED (not included) into the socket. **DO NOT EXCEED SPECIFIED WATTAGE.**
- Restore power to junction box and test fixture.

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

ARTERIOORS