


ASSEMBLY INSTRUCTIONS

ITEM DESCRIPTION:

ITEM NO.: 49330	NAME: Volta Pendant
MATERIAL TYPE: Steel/Glass	FINISH: Pale Brass/Opal
SOCKET TYPE: E26	SOCKET QTY: 1
BULB WATTAGE: 60W or/CFL 16W or/LED 13W	
VOLTAGE: 110-120 V	ITEM NET WEIGHT: 9.5LBS



PARTS INCLUDED:

A MOUNTING PLATE	1 PC	F FINIAL	1 PC
B CANOPY	1 PC	G SET RING	1 PC
C COLLAR LOOP	1 PC	H SOCKETS	1 PC
D1,D2,D3 ROD	4 PCS	I GLASS SHADE	1 PC
E MAIN BODY	1 PC		

HARDWARE INCLUDED:

J Plastic Wire Connector	L Allen Wrench
K Mounting Screws	Green Ground Screw

TO INSTALL YOU WILL NEED:

- 2 people recommended
- Phillips Screwdriver

These instructions are provided for safety. It is very important that they are read carefully and completely before beginning installation of this chandelier.

We strongly suggest that all hard-wired fixtures must be installed by a professional electrician.

TO ASSEMBLE:

1. Remove all packing contents from the carton(s) carefully. Ensure you have all parts indicated before you begin assembly.
2. Shut off the main electrical supply from the main fuse box/circuit breaker.
3. Remove the mounting plate(a)from the canopy(b)by turning collar loop (c) in a counterclockwise direction.
4. Screw the rod(d3) onto the top of main body(e) and tighten the hexangular screw in the side hole with Allen wrench(l) repeat the same operation on the rod(d1) and (d2). If the ceiling is high enough, pls assemble the rod(d4) if need.
5. As fig 1, unscrew the set ring (g) off the socket assembly(h), insert one type a 60w bulb (or suitable cfl 16w/led 13w, not included) in the socket. Do not exceed specified wattage. Then attach the glass shade(i) to the socket properly, and then screw the set ring (g)to secure the glass shade until tight.
6. Remove the mounting plate(a)from the canopy(b)by turning collar loop (c) in a counterclockwise direction.
7. Carefully inspect the pendant's fixture wires. The neutral fixture wire has very fine ridges molded into its plastic covering. The hot fixture wire has a smooth covering. The bare silver wire is the grounded wire.
8. Attach the ground wire from the fixture to the ground junction box wire from the outlet (usually green) or bare wire). Fasten each together with a plastic wire connector (j) and wrap the connection with electrical tape. If your outlet box does not have a ground wire, insert the green ground screw into the mounting plate (a) facing down, and wrap the fixture's bare ground wire around the ground screw. It is imperative that the outlet box in your home be properly grounded.
9. Connect the neutral fixture wire to the neutral junction box wire (usually white). Fasten each together with a wire connector (j) and wrap the connection with electrical tape. Be sure no strands are exposed.
10. Connect the hot fixture wire to the hot junction box wire (usually black). Fasten each together with a plastic wire connector (j) and wrap the connection with electrical tape. Be sure no wire strands are exposed. Do not reverse the hot and neutral connections or safety will be compromised.
11. Gently tuck the wire connections neatly into the ceiling junction box.
12. Attach the mounting plate (a) with nipple to the ceiling outlet box using the enclosed mounting screws (k) and tighten screws with a screwdriver.
13. Push collar loop in canopy (b) and thread onto nipple in mounting plate (a) by turning in a clockwise
14. Screw rod (d1) to canopy (b), using hexangular screw and Allen wrench(l) be sure all the hexangular screws are tight enough.
15. Screw the finial(f)onto the main body(e)till tight

CARE INSTRUCTIONS:

Wipe with a soft, dry cloth. To protect finish, avoid the use of chemicals and household cleaners.

For customer service questions call 1-800-338-2150

ARTERIO RS